

BROTHER 8710DW/8910DW/8950DWT

Toner Reset Instructions

8710/8910:

1. Open front door.
2. Press Clear.
3. Press *, 0, 0 (ignore the drum reset information).
4. Press OK.
5. Wait for screen to say "Accepted".
6. Close front door.

8950:

1. Open front door.
2. Press "1".
3. Select "Standard" in the window.
4. Press OK.
5. Wait for screen to say "Accepted".
6. Close front door.