

BROTHER Color Printer Toner Reset Instructions

1. If the printer is calling for any other supplies, be sure to reset them first.
2. Turn the machine off.
3. Unplug any USB or network or cables.
4. Turn the machine back on.
5. Open the front cover.
6. Press and hold the "Cancel" button down.
7. Press the "Reprint" or "Secure" button while still holding "Cancel".
8. Select the appropriate toner cartridge (B, M, C, or Y, usually ending in H for High Yield) with the arrow buttons.
9. Press OK
10. Select "Reset" with the arrow button.
11. Display will say "Accepted".
12. Close front cover.
13. Plug any USB or network or cables back in.